


ASSEMBLY, MAINTENANCE, & **USER MANUAL**

MODEL #SWTCS1300



WARNING

Read all precautions and instructions in this manual before using this equipment. Save this manual for future reference.
Maximum user weight 250 lbs.

SKYWALKER

TRAMPOLINES
Skywalker Holdings LLC
P.O. Box 574, Brigham City, UT 84302

TABLE OF CONTENTS

Part List.....	3
Part Identification.....	4-5
Exploded Drawing.....	6
Assembly.....	7-18
Maintenance and Care Information.....	19
Instructions for Use.....	20
Warning Label Placement.....	21
Instructions and Model Lessons.....	22-23
Trampoline Safety Information.....	24
Enclosure Safety Information.....	25
Methods of Accident Prevention.....	26
Limited Warranty.....	27



STOP EVERYTHING YOU'RE DOING AND REGISTER YOUR TRAMPOLINE

Find our warranty registration online by typing in: www.skywalkertrampolines.com/registration/

You'll need to have the following information handy:

- Name
- Address
- Phone number
- Date of purchase
- Email address
- Trampoline model number
- Trampoline serial number
- Retailer the trampoline was purchased from

HEY WE'VE GOT SOMETHING REALLY IMPORTANT TO SAY

And that is... check us out online! We've got **assembly videos** (for those of you who prefer movies over books), **FAQs** (so you know you're not the only one who messed up), fascinating **blog posts** (did you know jumping burns more calories than running?), and most importantly... find us on social media! Because we want to be your friend. **We'd love to hear from you, friend.**

Website: skywalkertrampolines.com

Facebook: facebook.com/skywalkertrampolines

YouTube: youtube.com/c/SkywalkerTrampolines

Pinterest: pinterest.com/swtrampolines

Twitter: twitter.com/swtrampolines

Instagram: instagram.com/skywalker_trampolines



IMPORTANT

Trampolines and enclosures are susceptible to winds. Be sure to secure your trampoline and enclosure. Wind damage is not covered in the warranty of your trampoline.



WARNING

CHOKING HAZARD- Small parts not for children under 3 years.



WARNING

Adult assembly required.

PART LIST

Key No.	Qty.	Description
1	4	Middle Frame Tube
2	8	Tube with Socket
3	4	Corner Tube
4	8	Leg Post
5	4	Male Leg
6	4	Female Leg
7	1	Enclosure Net
8	1	Jump Mat
9	84	Spring
10	1	Spring Pad
11	8	Straight Tube
12	8	Curved Tube
13	16	Foam (pre-installed)
14	8	Pole Cap
15	8	End Cap
16	20	M6x52mm Bolt
17	32	M6 Washer
18	20	M6 Nut
19	8	Self-tapping Screw
20	8	M5x44mm Bolt
21	1	Spring Tool
22	1	Screw Driver
23	1	Wrench
#	1	User Manual & Safety Placard
#	1	Set of ASTM Frame Labels

ORDERING REPLACEMENT PARTS

We get it... sometimes things happen. But the fun shouldn't stop just because you need a new bolt or screw! To order replacement parts, check out our website at: www.skywalkertrampolines.com or call our toll-free Customer Care Hot-line at **1-866-603-Jump (5867)**, Monday - Friday, 8 a.m. until 5 p.m. Mountain Time (excluding holidays).

Our customer service team will ask you a few questions in order to get the replacement part sent out as soon as possible. We're not trying to complicate your life, we promise.

When calling, make sure to have the following information ready:













- The model # of the product (see the front cover of this manual)
- The key # and description of the part (see the part list above)
- The quantity needed (only you know the answer to that one!)

BEFORE YOU BEGIN

Thanks for choosing Skywalker Trampolines! We're just as excited as you are to help your family live an active (but most importantly **FUN**) lifestyle. This model is one of our favorites, and we're confident you'll love it too. To make things easier for you, we've listed important information that you (and your little outdoor adventurers) need to know. Make sure you brush up on the warnings, instructions, assembly, maintenance, and use of your new product... because there will be a pop quiz at the end! (Okay, not **REALLY**, but if you're still reading this, props to you! You're awesome).


PART IDENTIFICATION

Before you begin, take a look at the drawings below to make sure you have all the parts! The numbers in the squares to the left (key numbers) will help you identify the parts during assembly.






13 Foam **(x16)**
(Pre-installed)



14 Pole Cap **(x8)**




15 End Cap **(x8)**




16 M6x52mm Bolt **(x20)**



17 M6 Washer **(x32)**




18 M6 Nut **(x20)**




19 Self-tapping
Screw **(x8)**




20 M5x44mm Bolt **(x8)**



21 Spring Tool **(x1)**




22 Screw Driver **(x1)**



23 Wrench **(x1)**

EXPLODED DRAWING



ASSEMBLY

READ THIS BEFORE YOU BEGIN


- You'll probably need at least **2 adults** and **2 hours** to assemble your trampoline (of course, that depends on what model you have, and whether or not you're secretly a superhero).
- We've provided a Phillip's screw driver and one adjustable wrench to help with assembly, but you're more than welcome to use your own tools. Many find that using a power drill and a rubber mallet makes things easier.
- Use gloves to protect your hands from pinch points during assembly. Plus, it's an up-and-coming fashion trend.
- The assembly steps refer to parts by their descriptions and key numbers (see the part list on page 3).
- The assembly steps are written in a specific order, and if you don't follow them exactly... you may end up having to start all over again. We promise we won't say, "I told you so" but really... we told you so.
- Most importantly... **YOU'VE GOT THIS. YOU'RE THE BEST TRAMPOLINE ASSEMBLER AROUND.** This may not be the easiest thing you've ever done... but it will be **worth it.** Trust us.

And if you're a visual learner, check out our assembly videos! **YouTube** Visit: youtube.com/c/SkywalkerTrampolines

STEP 1

Register your trampoline! For info on **warranty registration**, see page 2.

STEP 2




2 Top tube with Socket (x8)



3 Corner Tube (x4)


Insert two top tubes with sockets **(2)** into one corner tube **(3)**. Repeat this step to assemble all four corner sections.

Make sure the holes in the tubes face the ground!




ASSEMBLY

STEP 3



4 Leg Post (x8)



16 M6x52 Bolt (x8)



17 M6 Washer (x8)



18 M6 Nut (x8)

Insert two leg posts **(4)** into the sockets, and secure using two M6x52mm bolts **(16)**, two M6 washers **(17)** and two M6 nuts **(18)**.

Repeat this step until all eight leg posts are assembled.




STEP 4



5 Male Leg (x1)




6 Female Leg (x1)



16 M6x52mm Bolt (x4)




17 M6 Washer (x8)




18 M6 Nut (x4)

Insert one male leg **(5)** into one female leg **(6)**, and secure with one M6x52mm bolt **(16)**, two M6 washers **(17)**, and one M6 nut **(18)**.

Repeat this step until you have made four U-shaped leg sections.



STEP 5



16 M6x52mm Bolt (x8)




17 M6 Washer (x16)




18 M6 Nut (x8)

Insert one U-shaped leg section into the leg posts of a corner frame section. Make sure the holes of the U-leg match the holes of the leg posts. Secure with two M6x52mm bolts **(16)**, four M6 washers **(17)**, and two M6 nuts **(18)**. Repeat this step until four corner leg sections are assembled.




STEP 6




1 Middle Frame Tube (x2)

Grab a friend and flip the assembled corner leg sections over so they are now standing on the legs. (Do not skip this step! We're not underestimating your strength or anything, but if you connect before flipping, the entire frame will be too heavy to flip.) Now place a middle frame tube **(1)** (bend facing out) in between two corner leg sections and slide them together. Repeat on the other side. You will now have two square frame halves assembled.



ASSEMBLY


STEP 7




1 Middle Frame Tube (x2)

Now, place two middle frame tubes (**bend facing out**) between the two frame halves. Slide the two halves of the trampoline together to create a free standing frame.


Note: Tighten all the bolts to secure into place.



STEP 8





7 Enclosure Net (x1)



8 Jump Mat (x1)


The enclosure net **(7)** will be pre-installed to the jump mat **(8)** (Just trying to save you a minute or two...). Before continuing, make sure each V-ring of the jump mat is properly threaded through the corresponding hole in the enclosure net.



STEP 9

Place the jump mat on the ground inside the frame with the enclosure net on top.


Be sure to **center the enclosure door** in between the third and fourth hole on the **middle** frame tube.



STEP 10




You may want to use gloves for this step! Using the spring tool (21), hook the smaller end of a spring (9) into the V-Ring just right of the warning label. Stretch the free end of the spring until it reaches the 4th hole on middle frame tube (1).





ASSEMBLY

STEP 11



9 Spring (x1)

Attach one spring on the **opposite** middle frame tube. You should now have two springs attached.





STEP 12




9 Spring (x2)

Starting with the spring just placed, count **21 V-rings and 21 spring holes** to the right, and attach one spring. Then, count **21 V-rings and 21 spring holes** to the left, and attach one spring.

You should now have four springs attached, one on each side of the trampoline.





STEP 13




9 Spring (x32)

There will be **16 connection sections** on the frame. Attach **one spring on either side** of the 16 connections. You should now have a total of 36 springs attached.




STEP 14



9 Spring (x48)


Now, working in a **clockwise direction**, attach all of the remaining springs. **Make sure the V-rings and frame holes line up correctly!**

(Remember, you're the boss here. You tell those springs what to do! And other people if they're helping...)



ASSEMBLY



STEP 15



10 Spring Pad (x1)




Lay the spring pad **(10)** on the frame. Adjust the spring pad so that the **slits** are directly **above** the T-sockets.

Important: Don't use the trampoline without the frame pad. It's designed to protect your little jumpers! Trust us on this one.




STEP 16


Look under the trampoline and find the straps that are attached to the underside of the spring pad **(10)**. Position the **outer straps** so that one strap is on **each side of the frame**. Position the **inner straps** so that one strap is **threaded through a V-ring**. Now tie all of the straps in **bows**. (Because if you tie them in knots, you'll have a pretty hard time untying them ever again!) Secure the corners of the spring pad to the frame using the attached straps. Hook the straps to the **V-rings at each corner**.




STEP 17



If you want, take a snack break because you're MORE THAN HALFWAY DONE, and you deserve it. **If the foam is already installed to the tubes, then skip this step!** If not, just slide all the straight tubes **(11)** and curved tubes **(12)** into the foam **(13)**. If you're having trouble getting the foam over the tubes, try adding a small amount of water inside the foam!




STEP 18



19 Self-tapping Screw (x8)


Insert one straight tube **(11)** into one curved tube **(12)**, and secure with one self-tapping screw **(19)**. **Important: On the curved tube there is one end that has two holes. Make sure that end is on top!**

Repeat this step to attach the seven remaining straight tubes and curved tubes together.






ASSEMBLY

STEP 19




14 Pole Cap (x8)

Important: The pole cap (14) has two sides; one with a hexagon hole, and one with a round hole. Insert the pole caps into the strap rings found on the top of the enclosure net. Make sure the hexagon holes are facing the net, and the round holes are facing you.





STEP 20



20 M5x44mm Bolt (x8)


Next insert a curved tube (12) into the pole cap (14). Make sure the bent side of the enclosure poles are facing towards the center of the trampoline. Make sure the holes on the curved tube, pole cap, and strap ring are all aligned. Then insert a M5x44mm bolt (20) to secure in place. **Important: Make sure the bolt goes into the round hole FIRST (not the hexagon hole) or you could break the pole cap!** Repeat this step with the remaining curved tubes.




STEP 21

Starting from the enclosure door, lift one of the assembled poles and insert the straight tube **(11)** into the socket. Repeat this process to assemble the seven remaining poles.

Helpful tip: When inserting the enclosure poles, pull back on the middle of the poles!




STEP 22



15 End Cap (x8)

Next, insert the end caps **(15)** into the bottom of the sockets.




ASSEMBLY

STEP 23


LAST STEP YOU'RE IN THE FINAL HOME STRETCH.

Using the included plastic tie, attach the safety placard to the trampoline frame close to the enclosure door.



STEP 24

Congratulations on completing your new trampoline! (See... we knew you could do it!) So here comes the real question... **are you satisfied with this completed product?** If you are, go ahead and **write a review** on the retailer's site you bought it from. We'd really appreciate it... and if we could, we'd give you a gold star. Are you completely frustrated and have some choice words for us? Contact us directly! We're not trying to ruin your life, we promise. And we'll do everything we can to make it right again. See contact info on page 2-3.



MAINTENANCE & CARE INFORMATION

Congratulations and **high five** on successfully assembling your new Skywalker Trampolines 13' Square Trampoline with Enclosure! Now, the best way to keep your new trampoline in tip top shape, is to periodically check for:

- Missing, improperly positioned, or insecurely attached frame padding, netting, enclosure tubes, or foam sleeves
- Punctures, frays, tears, or holes worn in the mat, frame padding, netting or foam sleeves
- Deterioration in the stitching or fabric of the mat, frame padding or netting
- Ruptured or missing springs
- Bent or broken frame, leg or enclosure tubes
- Sagging bed or netting
- Sharp protrusions on the frame, suspension system or enclosure tubes

If you notice any of the above conditions, please disassemble the trampoline and/or the enclosure net until new parts are ordered!

Moving the Trampoline and Enclosure

If the trampoline and enclosure needs to be moved, it should be moved by two persons, kept horizontal, and lifted slightly. If necessary, the trampoline and enclosure can be taken apart for moving. To take the trampoline apart, follow the assembly steps in reverse order. Do not attempt to take the frame sections, legs, or bases apart before the mat and springs have been removed.

Don't forget to check us out online! **We'd love to hear from you.**

Website: skywalkertrampolines.com

Facebook: facebook.com/skywalkertrampolines

YouTube: youtube.com/channel/UCUty7EqwIGouK5ovzGpHGrw/feed

Pinterest: pinterest.com/swtrampolines

Twitter: twitter.com/swtrampolines?lang=en

Instagram: instagram.com/skywalker_trampolines/?hl=en

INSTRUCTIONS FOR USE

To reduce the risk of serious injury, read and follow all of the warnings, precautions, and instructions in this manual before you use the trampoline enclosure. Warnings and instructions for care, maintenance, and use of this trampoline and enclosure are included to promote safe enjoyable use of this equipment.

1. It is the responsibility of the owner and supervisors of the trampoline and enclosure to make sure all users obey the safety instructions given in this manual. The trampoline should only be used with mature, knowledgeable supervision.
2. Secure the trampoline and trampoline enclosure against unauthorized and unsupervised use. If you use a ladder to get on and off the trampoline, be sure to remove it when the trampoline and enclosure are not being used.
3. Be sure there is enough clear space above the trampoline and enclosure before use. It is best to have at least 24 feet (7.3 meters) of clear space above the ground. This space must be clear of wires, tree limbs, and any other possible hazards.
4. Lateral (sideways) clearance is very important. Do not place the trampoline and enclosure near walls, buildings, fences, sidewalks, and other play areas. Always keep a clear space on all sides of the trampoline and enclosure.
5. Remove any objects that could interfere with the performer. Maintain a clear area around and under the trampoline.
6. Be sure the trampoline and enclosure are on a level surface before use.
7. Always inspect the trampoline and enclosure before each use. Make sure that the frame, padding, netting, enclosure tubes, and foam sleeves are correctly and securely positioned. Replace any worn, defective, or missing parts. (Jumpers may be hurt if the trampoline and enclosure are used when they are in poor condition.)
8. Bounce only when the surface of the mat (bed) is dry. There should be very little or no wind or air movement. The trampoline and enclosure must not be used in gusty or severe winds.
9. The trampoline and enclosure frames are made of metal. They are not grounded and will conduct electricity. For this reason, an electrocution hazard exists. No lights, electric heaters, extension cords, or household electrical appliances are to be permitted on the trampoline or in enclosure at any time.
10. Use the trampoline and enclosure in an area with lots of light. If the trampoline and enclosure are indoors or in shady areas, you may need to use artificial (electrical) lighting in the area.
11. During the winter months, the trampoline soft materials will need to be removed and stored in a dry place. If left up in the winter months, it may cause damage to the springs, jump mat, spring pad, and enclosure. The warranty will be void.
12. This trampoline and enclosure is made for users who weigh less than 250 lbs.
13. Trampoline over 20 in. (51 cm) tall are not recommended for use by children under 6 years of age.
14. The trampoline enclosure is to be used only with the size of trampoline for which the enclosure is designed.
15. Misuse and abuse of the trampoline enclosure is dangerous and can cause serious injury.
16. Do not attach anything to the enclosure barrier that is not a manufacturer-approved accessory or part of the enclosure system.
17. Please remove any jewelry before jumping begins. Jewelry may get caught in the enclosure netting.
18. Wear clothing free of drawstrings, hooks, loops, or anything that could be caught while using the trampoline/enclosure and result in entanglement, strangulation, or both.
19. DO NOT let more than one person inside the trampoline enclosure at the same time. Two or more people jumping at the same time can cause serious injury.
20. DO NOT jump on the trampoline while you have or are holding any objects, especially something sharp or breakable.
21. DO NOT use the trampoline and enclosure if you have been using alcohol or drugs.
22. DO NOT attempt or allow somersaults (flips) on the trampoline. Landing on the head or neck can cause serious injury, paralysis, or death, even when landing in the middle of the jumping mat.
23. Always climb on to and off of the trampoline. It is a dangerous practice to jump from the trampoline to the floor or ground when dismounting, or to jump onto the trampoline when mounting.
24. DO NOT use the trampoline as a springboard to other objects. Enter and exit the enclosure only at the enclosure door or barrier made for that purpose.
25. DO NOT attempt to crawl under, jump over, intentionally bounce off of, hang from, climb on, kick, or cut the barrier netting.
26. While keeping head erect, focus eyes on the trampoline toward the perimeter. This will help control bounce.
27. Stop bouncing by flexing knees as feet come in contact with the trampoline bed. Learn this skill before attempting others.
28. Avoid bouncing too high. Stay low until bounce control and repeated landings in the center of the trampoline can be accomplished. Control is more important than height.
29. Avoid bouncing when tired. Keep turns short.
30. Learn fundamental bounces and body positions thoroughly before trying more advanced skills. A variety of trampoline activities can be carried out performing the basic fundamentals in various series and combinations, performing one fundamental after another, with feet bounces between them.
31. For additional information concerning the trampoline equipment contact the manufacturer. For information concerning skill training, contact a certified trampoline instructor.
32. Do not use or stand near the trampoline in windy or gusty conditions. A trampoline can become airborne when exposed to sustained wind or gusting wind conditions. This can result in serious injury, paralysis, or death, as well as property damage. To reduce these risks, disassemble the trampoline and enclosure and store them until weather conditions improve. Anchoring a trampoline frame may prevent the trampoline from moving as a result of the wind, but even anchored trampolines can become airborne or damaged. Consult a qualified contractor to determine what type of anchor works best in your location.

WARNING LABEL PLACEMENT

WARNING

Do not attempt or allow somersaults. Landing on your head or neck can cause serious injury, paralysis, or death, even when landing in the middle of the mat. Use trampoline only with mature, knowledgeable supervision.

Only one person at a time on the trampoline. Do not allow more than one person on the trampoline. Use by more than one person at the same time increases the chance of injury. Use trampoline only with mature, knowledgeable supervision. This trampoline is not recommended for children under 6 years of age.

For the Supervisor:
Read the instructions before using the trampoline. Enforce all of the safety rules and be familiar with the information in the User Manual to help new users learn basic jumps and all users to follow trampoline safety.

All trampoline users must have mature, knowledgeable supervision, regardless of the skill or age of the jumper.

This trampoline is not recommended for use by children under 6 years of age.

Inspect the trampoline before using. Keep frame pad in place. A worn or damaged mat (bed), spring, or frame piece should be replaced immediately.

Keep objects away that could interfere with the jumper.

Secure the trampoline against unauthorized and unsupervised use.

Do not use when trampoline is wet or in a windy condition.

For the Jumper:
Do not use the trampoline when under the influence of drugs or alcohol.

Avoid bouncing when tired.

Jumping:
Learn the basic jumps and body positions very well before trying more difficult stunts. Study the User Manual to learn how to do basic jumps.

Stop your bounce by flexing your knees as your feet come in contact with the trampoline mat (bed).

Avoid jumping too high or for too long. Always control your jump. A controlled jump is one where the take of and land spots are the same.

Bounce in the center of the trampoline. Focus eyes on trampoline toward the perimeter mat. Failure to do so may result in a loss of balance and control.

Take turns jumping one at a time, and always have someone watch you.

Getting on and off:
Climb on to and off the trampoline. Do not jump on or off. Do not use the trampoline as a springboard to other objects.

For further equipment information contact Skywalker. For skill training information, contact a trainer certification organization.

ATTACH TO TRAMPOLINE

WARNING

Do not attempt or allow somersaults. Landing on your head or neck can cause serious injury, paralysis, or death, even when landing in the middle of the mat. Use trampoline only with mature, knowledgeable supervision. Do not allow more than one person on the trampoline. Use by more than one person at the same time increases the chance of injury. Use trampoline only with mature, knowledgeable supervision. This trampoline is not recommended for children under 6 years of age.

WARNING

Do not attempt or allow somersaults (Flips)

Do not land on head or neck.

Landing on your head or neck can cause serious injury, paralysis, or death, even when landing in the middle of the mat.

Use trampoline only with mature, knowledgeable supervision.


Do not allow more than one person on the trampoline. Multiple jumpers increase the chance of loss of control, collision and falling off. This can result in broken head, neck, back, or legs.

Use Trampoline only with mature, knowledgeable supervision.

This trampoline is not recommended for children under 6 years of age.

Read all of the instructions before using this trampoline.

Inspect before using and replace any worn, defective or missing parts.



WARNING

Do not land on head or neck.

Do land on head or neck. Paralysis or death can result, even if you land in the middle of the trampoline mat (bed). Do not do somersaults (flips).

Use trampoline enclosure only with mature, knowledgeable supervision. Enforce all safety rules and be familiar with the information in the User's manual to help users in following enclosure instructions and trampolines safety.

Only one person at a time on the trampoline. Multiple jumpers increase the chance of loss of control and this can result in broken head, back or leg. Users may become entangled in or strangled by loose cards or gaps between trampoline and enclosure.

For the Supervisor:
Use trampoline enclosure only with mature, knowledgeable supervision. Enforce all safety rules and be familiar with the information in the users manual to help users in following trampoline enclosure instructions and trampoline safety.

This trampoline enclosure system is not recommended for use by children under 6 years of age.

Do not exceed the weight limit recommended by the manufacturer.

Use only when the trampoline mat (bed) is clean and dry. Inspect the trampoline and enclosure prior to each use and replace any worn or damaged parts.

Use only when enclosure barrier has no holes, pole clamps are tightly secured to the poles, and the support (frame) and the barrier is properly suspended.

For the Jumper:
Do not use the trampoline when under the influence of drugs or alcohol.

Jumping:
Avoid jumping too high for too long. Always control your jump. Do not try to jump over the barrier.

Do not intentionally rebound of the barrier. Do not hang from, kick, out or climb on the barrier.


Wear clothing free of drawstrings, hooks, loops, or anything that could get caught while using the trampoline/ enclosure and result in entanglement or stranglement or both.

Getting on and off:
Climb on to and off the trampoline at the enclosure door or barrier opening. Do not jump on or off. Do not crawl under the barrier. Do not use the trampoline as a springboard to other objects.

Do not jump from other objects, buildings, or surfaces, onto the trampoline, or into or over the trampoline enclosure.

For further equipment information contact Skywalker Trampolines. For skill training information, contact a trainer certification organization.

ATTACH TO NETTING AT DOOR



The placard shown above was sewn to the trampoline enclosure netting.

Note: The labels and placard shown are not actual size.

The labels shown on this page have been attached to the trampoline in the indicated locations. The safety instructions placard will need to be attached by the owner. If one of the labels or the placard is missing or illegible, call our Customer Care Hot Line toll-free at 1-866-603-JUMP (5867), Monday through Friday, 8 a.m. until 5 p.m. Mountain Time, to order a free replacement label or placard.


INSTRUCTIONS & MODEL LESSONS

The following lessons are examples of an instructional program. They should follow a complete discussion and demonstration of body mechanics between the supervision and the student(s).

1. Mounting and dismounting: Demonstration and practice of proper techniques.
2. Fundamental bounce: Demonstration and practice.
3. Breaking: Demonstration and practice. Breaking on command.
4. Hand and knee drop: Demonstration and practice, stressing four-point landing and alignment.


Lesson 1: Fundamental Bounce

1. Start from a standing position with your head erect and your eyes on the frame pad.
2. Swing your arms forward and up in a circular motion.
3. Bring your feet together and point your toes downward while in the air.
4. Keep your feet about 15 inches apart when landing on the mat.




Lesson 2: Knee Drop

1. Start bouncing from a standing position, keeping your eyes on the frame pad.
2. Land on your knees, keeping your back straight and your body erect.
3. Come back up to an erect position.




Lesson 3: Hand and Knee Drop

1. Start bouncing from a standing position, keeping your eyes on the frame pad.
2. Land on the mat on your hands and knees.
3. Push with your hands and come back up to an erect position.




Lesson 4: Back Drop

1. Start from a low bounce and land on your back.
3. Keep your chin forward on your chest as you land.
4. Kick forward and up with your legs to return to an erect position.




Lesson 5: Seat Drop

1. Land in a sitting position with your legs parallel to the mat.
2. Place your hands on the mat beside your hips.
3. Push with your hands to return to an erect position.




Lesson 6: Front Drop

1. Start from a low bounce and land on the mat in a prone position.
2. Keep your head up and your arms extended forward on the mat.
3. Push with your arms to return to an erect position.



Lesson 7: Half Turntable

1. Start from the front drop position and push to the left or right with your arms turning your body in the opposite direction.
2. Turn your head and shoulders toward the direction that your body is turning.
4. Keep your back parallel to the mat and your head up.
5. After completing a half turn, land in the front drop position.



Lesson 8: Swivel Hips

1. Start with a seat drop.
3. Turn your head to the left or right and swing your arms up in the same direction.
4. Turn your hips in the same direction as your head and arms, completing a twist.
5. Land in the seat drop position.
4. Keep your back parallel to the mat and your head up.
5. After completing a half turn, land in the front drop position.



Once each of lessons are learned, the student should now be encouraged to design and organize routines, with emphasis on good form. The instructor may judge or grade students and arrange groupings for further instruction accordingly.

To stimulate interest in competition, the game of "Trampoline Horse" can be introduced. Before the game begins, students must count off. To start the game, student number 1 performs a stunt. Student number 2 then mounts the trampoline, performs the same stunt and adds a second stunt. Student number 3 mounts and performs stunts 1 and 2 and adds a third stunt. Thus the series of stunts is continuously lengthened. The first person to miss a stunt in the series assumes the letter "H" and starts a new series with a stunt. If a person misses again, he assumes the letter "O." When a person accumulates "H-O-R-S-E," he or she is eliminated from the game. The last remaining contestant is the winner. Lesson planning from this point on should be facilitated by contacting a certified trampoline instructor.

TRAMPOLINE SAFETY INFORMATION

In trampoline use, as in all active recreational sports, participants can be injured. However, there are steps that can be taken to reduce risk of injury. In this section, primary accident patterns are identified and the responsibilities of supervisors and jumpers in accident prevention are described.

ACCIDENT CLASSIFICATION

Somersaults (flips): Landing on your head or neck, even in the middle of the trampoline mat, increases the risk of a broken back or neck, which can result in paralysis or death. Such events can occur when a jumper makes an error trying to perform a forward or backward somersault (flip). Do not perform somersaults(flips) on this backyard trampoline.

Multiple Jumpers: More than one jumper at a time on the trampoline increases the chance of a jumper becoming injured by losing control of his or her jump. Jumpers may collide with one another, fall off of the trampoline, fall onto or through the springs, or land incorrectly on the mat. The jumper weighing the least is the jumper most likely to be injured.

Mounting and Dismounting (Getting on and off): The trampoline mat is several feet above ground level. Jumping from the trampoline to the ground or any other surface may result in injury. Jumping onto the trampoline from a roof, deck, or other objects also presents a risk of injury. Smaller children may need assistance getting onto or down from the trampoline. Climb carefully onto and off of the trampoline. Do not step onto the springs or the fame pad. Do not grasp the frame pad to pull yourself onto the trampoline.

Striking the Frame or the Springs: Injury may result from hitting the frame or falling through the springs while jumping or getting onto or off of the trampoline. Stay in the center of the mat when jumping. Be sure to keep the frame pad in place to cover the fame. The frame pad is not made or intended to support the weight of trampoline user. Do not step or jump directly on the frame pad.

Loss of Control: Jumpers who lose control of their jumps may land on the mat incorrectly, land on the frame or springs, or fall off of the trampoline. A controlled jump is one where the landing is in the same spot as the takeoff. Before learning a more difficult stunt, you should be able to do one over an over with control. Attempting a stunt beyond present skill levels increases the chance of loss of control. To regain control and stop your jump bend your knees sharply when you land.

Alcohol or Drug Use: The chance of injury increases when a jumper has consumed alcohol or taken drugs. These substances impair a person's reaction time, judgment, and physical coordination.

Encountering Objects: Jumping on a trampoline while other people, pets, or objects are underneath it will increase the chance of getting hurt. Jumping while holding or having an object on the trampoline, particularly one that is sharp or breakable, will increase the chance of injury. Placing a trampoline too close to overhead electrical wires, tree limbs, or other objects can increase the chance of injury.

Poor Maintenance of The Trampoline: Jumpers may be injured if a trampoline is in poor condition. A torn mat, bent frame, broken spring, or missing frame pad, for example, should be replaced before anyone is allowed to jump. Inspect the trampoline before each use.

Weather Conditions: A wet trampoline is too slippery for safe jumping. Gusty or high winds can cause jumpers to lose control. To reduce the chance of injury, use the trampoline only when the weather is good.

Access: To prevent access to the trampoline by unsupervised smaller children, the optional access ladder should always be taken away and stored in a safe place when the trampoline is not in use.

ENCLOSURE SAFETY INFORMATION

NEED FOR TRAMPOLINE ENCLOSURE SAFETY

A trampoline enclosure is a recreational product. The information on this page identifies important safety precautions. The precautions are not all-inclusive, because an enclosure can be used in ways that this manual cannot cover completely.

To prevent pinches and cuts during enclosure use, a frame pad must be installed on the trampoline (see the trampoline manufacturer's instructions). The frame pad must be placed on the trampoline before the enclosure is erected. The frame pad reduces the chance of injury from accidental contact with the springs and frame.

USING THE ENCLOSURE SAFELY

Adult Supervision of Children

Children using a trampoline with a trampoline enclosure must be supervised by adults. Young children must be supervised constantly. Adults must pay particular attention to:

- Things that children bring into the enclosure
- Children's activities inside the enclosure
- Conditions inside the enclosure while children are using it
- The way children enter and exit the enclosure

Additional details of safety enclosure use are described below:

Electrocution Hazard Associated with the Metal Frame of the Trampoline and Enclosure

The trampoline and enclosure frames are made of galvanized steel. They are not grounded and will conduct electricity. For this reason, an electrocution hazard exists. No lights, electric heaters, extension cords, or household electrical appliances are to be permitted on the trampoline or in the enclosure at any time.

Hazards Associated with Entering and Exiting the Trampoline Enclosure

A trampoline enclosure installed on a trampoline is raised off the ground. The height of the enclosure increases the risk of a fall when a jumper is entering or leaving the enclosure. Young children especially may have difficulty entering and exiting the enclosure. To reduce the risk of falling, always help young children to get into and out of the enclosure.

Enter and exit the trampoline enclosure only through the door of the enclosure (the opening in the netting walls). The trampoline mat (bed) and the netting walls of the enclosure are separate pieces. No jumper, especially young children, should ever leave the enclosure by going out between the mat and the netting walls. Trying to get out this way creates a risk of choking from being caught between the trampoline frame and the netting walls.

Darkness increases the chances of a fall when a jumper is entering or leaving the enclosure. Do not use the trampoline unless there is plenty of lighting provided.

Hazards Associated with Animals, Sharp or Breakable Objects

To avoid damage to the trampoline enclosure and the trampoline, do not allow pets or other animals inside of the enclosure. The claws and teeth of animals can damage the netting. Do not jump on the trampoline while holding or wearing a sharp or breakable object.

METHODS OF ACCIDENT PREVENTION

THE SUPERVISOR'S ROLE IN PREVENTING ACCIDENTS

It is the responsibility of the supervisors of trampoline users to provide knowledgeable and mature supervision. They need to know and enforce all of the rules and warnings printed in this manual to minimize the likelihood of accidents and injuries. They also need to inform users of these rules. During periods of time when supervision is unavailable or inadequate, this may require that the trampoline is taken down, placed in a secure area, or otherwise secured against unauthorized use. Another option that may be considered is covering the trampoline with a heavy tarp that can be secured with locks and chains. It is the responsibility of the supervisor to make sure that the placard with trampoline safety instructions is kept posted on the trampoline and that jumpers are informed about these instructions.

THE JUMPER'S ROLE IN PREVENTING ACCIDENTS

Education on the part of the user is a must for safety. Users must first learn a low, controlled bounce and then learn the basic landing positions and combinations before proceeding to intermediate skills. Jumpers must understand why they have to master "control" before they can start thinking about other moves. Understanding the proper progression of skills in jumping on a trampoline must be the first lesson. Review this manual to learn about the basic techniques for using the trampoline. Follow the rules on the placard with trampoline safety instructions (see step [22] in assembly instructions). For further information or additional instructional materials, contact a certified trampoline instructor.

TRAMPOLINE SAFETY INSTRUCTIONS

For the Supervisor

Read the instructions before using the trampoline. Enforce all of the safety rules. Become familiar with the information in this manual so you can help new users learn basic jumps and all users follow trampoline safety. All trampoline users must have mature, knowledgeable supervision, regardless of their skill or age. This trampoline is not recommended for use by children under 6 years of age. Inspect the trampoline before using it. Do not use the trampoline without the frame pad securely in place to cover the frame. Do not use the trampoline in wet or windy conditions. A worn or damaged mat, spring, or frame piece should be replaced immediately.

Jumping

Learn fundamental jumps and body positions thoroughly before trying more advanced skills. Know your own limits in performing each of the trampoline jumps. Study this manual to learn how to do basic jumps. Stop your bounce by flexing your knees as your feet come in contact with the trampoline mat. Learn this skill before attempting any others.

HAZARDS ASSOCIATED WITH HIGH WINDS

A trampoline with an enclosure can be moved or blown over by high winds. Anyone in its path, or inside of the enclosure, may be injured if this happens. If you expect high winds, take down the enclosure netting and stake the trampoline frame to the ground, or move the trampoline and enclosure to a sheltered location. The only sure method to protect your trampoline and the surrounding environment during high winds is to completely disassemble the unit and store indoors. Damage due to wind or weather is not warranted.

LIMITED WARRANTY

Skywalker Holdings, LLC warrants its products to be free from defects in material and workmanship under normal use and service conditions. **The steel frame is warranted for three (3) years after the date of purchase. All other parts are warranted for one (1) year after the date of purchase.** Warranty coverage extends only to the original retail purchaser from the date of original purchase. This warranty is only valid concerning products used for residential use. Products used for commercial use, such as schools and daycares, will not be covered.

WHAT IS NOT COVERED?



Weather Damage: The warranty does not cover damage due to the effects or acts of nature, such as earthquakes, wind, hurricanes, tornadoes, lightning, rain, fire, snow, excessive heat and cold conditions and/or sun damage. During the winter months the trampoline soft materials will need to be removed and stored in a dry place out of the snow. If left unprotected in the winter months, some components such as springs, jump mat, spring pad and enclosure, may become damaged, voiding this warranty.



Fading and Rust: Our products are fully galvanized. Skywalker does not warranty against rust or corrosion. Some areas may have higher air salt content, higher humidity, heavier rain and heavier snow. Skywalker does not warranty against fading. We suggests customers use a UV protectant on the frame pad to extend the life of the product.



Loss or damage to Product Due to: **Loss or damage caused during** shipping or caused by abuse, misuse, improper or abnormal usage or authorized repair are not covered by this warranty and may also void the warranty.



Unauthorized Replacement Parts: The warranty will become void if any defects or damages are associated with the use of unauthorized replacement parts. All replacement parts must be obtained from an authorized agent.



Assembly Service: The warranty does not cover acts or omissions provided by a third-party assembly service. It is the customer's responsibility to check all boxes and confirm all components are included and in their proper condition before installation occurs.

INSPECTION AND REPLACEMENT PARTS:

1. Your trampoline SHOULD BE INSPECTED UPON UNPACKING AND SET UP AND THEREAFTER ON A REGULAR BASIS. WORN, DAMAGED OR BROKEN PARTS SHOULD BE REPLACED IMMEDIATELY AND BEFORE USE.
2. Call the Skywalker Trampoline Customer Service Department at 1-866-603-5867 to file a warranty claim. Be prepared to provide the following information: name, shipping address, a copy of your original sales receipt, a brief description of the problem and cause, trampoline model number and serial number. We may also ask for photos of the damaged/defective parts.
3. After reviewing your information and examining your photos, Skywalker Trampolines will make the determination if this part is covered by this warranty. If so, a replacement part will be sent to you.

NOTE: All requested information must be provided in order to review your warranty claim.

To order replacement parts for your product please visit www.skywalkertrampolines.com

Skywalker Holdings, LLC, PO Box 574, Brigham City, UT 84302 USA.

Printed in China © 2017 Skywalker Holdings, LLC


NOTE: SKYWALKER HOLDINGS, LLC IS NOT RESPONSIBLE OR LIABLE FOR INDIRECT, SPECIAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THE PRODUCT OR OTHER DAMAGES WITH RESPECT TO ANY ECONOMIC LOSS, LOSS OF PROPERTY, LOSS OF REVENUE OR PROFITS, LOSS OF ENJOYMENT OR USE, COST OF REMOVAL, INSTALLATION OR OTHER CONSEQUENTIAL DAMAGES. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES. ACCORDINGLY, THE ABOVE LIMITATION MAY NOT APPLY TO YOU.

THE WARRANTY EXTENDED HEREUNDER IS IN LIEU OF ALL OTHER WARRANTIES AND ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE IS LIMITED IN ITS SCOPE AND DURATION TO THE TERMS SET FORTH HEREIN. SOME STATES OR COUNTRIES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS. ACCORDINGLY, THE ABOVE LIMITATION MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS. YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY STATE TO STATE OR COUNTRY TO COUNTRY.

THIS WARRANTY IS VALID ONLY IN THE COUNTRY THE PRODUCT WAS PURCHASED.

MANUAL DE MONTAJE Y MANTENIMIENTO PARA EL USUARIO

MODELO N.º SWTCS1300



ADVERTENCIA

Lea todas las precauciones e instrucciones de este manual antes de utilizar este producto. Guarde este manual para consultarlo en el futuro. **Peso máximo del usuario: 250 lb.**

SKYWALKER

TRAMPOLINES
Skywalker Holdings LLC
P.O. Box 574, Brigham City, UT 84302

ÍNDICE

Lista de piezas	3
Identificación de piezas.....	4-5
Dibujo de despiece	6
Montaje	7-18
Información de mantenimiento y cuidado.....	19
Instrucciones de uso.....	20
Posición de etiqueta de advertencia.....	21
Instrucciones y lecciones modelo.....	22-23
Información de seguridad sobre el trampolín.....	24
Información de seguridad sobre el cerramiento.....	25
Métodos para evitar accidentes.....	26
Garantía limitada.....	27



DEJE TODO LO QUE ESTÁ HACIENDO Y REGISTRE SU TRAMPOLÍN

Encontrará nuestro registro de garantía en línea ingresando en: www.skywalkertrampolines.com/registration/

Deberá tener la siguiente información a mano:

- Nombre
- Dirección
- Número de teléfono
- Fecha de compra
- Correo electrónico
- Número de modelo del trampolín
- Número de serie del trampolín
- Vendedor al que le compró el trampolín

TENEMOS ALGO MUY IMPORTANTE QUE DECIRLE

¡Visite nuestra página web! Tenemos videos del montaje (para quienes prefieren ver en vez de leer), **preguntas frecuentes** (para que sepa si otra persona tuvo la misma pregunta que usted), publicaciones fascinantes en **blogs** (¿sabía que saltar permite quemar más calorías que correr?) y lo más importante... ¡puede encontrarlos en las redes sociales! Porque queremos ser su amigo. **¡Nos encantaría estar en contacto con usted!**

Sitio web: skywalkertrampolines.com
Facebook: facebook.com/skywalkertrampolines
YouTube: youtube.com/c/SkywalkerTrampolines

Pinterest: pinterest.com/swtrampolines
Twitter: twitter.com/swtrampolines
Instagram: instagram.com/skywalker_trampolines



¡IMPORTANTE

Los trampolines y los cerramientos pueden dañarse con el viento. Asegúrese de fijar el trampolín y el cerramiento. La garantía de su trampolín no cubre los daños ocasionados por el viento.



ADVERTENCIA

PELIGRO DE ASFIXIA: las partes pequeñas no son para niños menores de 3 años.



ADVERTENCIA

Es necesario que el montaje lo realice un adulto.

LISTA DE PIEZAS

N.º de ref.	Cant.	Descripción
1	4	Tubo central del armazón
2	8	Tubo con maguito
3	4	Tubo esquinero
4	8	Poste de la pata
5	4	Pata macho
6	4	Pata hembra
7	1	Red del cerramiento
8	1	Lona de salto
9	84	Resorte
10	1	Almohadilla del resorte
11	8	Tubo recto
12	8	Tubo curvo
13	16	Gomaspumá (preinstalada)
14	8	Tapa del poste
15	8	Tapa del extremo
16	20	Perno M6 x 52 mm
17	32	Arandela M6
18	20	Tuerca M6
19	8	Tornillo autorroscante
20	8	Perno M5 x 44 mm
21	1	Herramienta para el resorte
22	1	Destornillador
23	1	Llave
#	1	Manual del usuario y letra de seguridad
	1	Juego de etiquetas del armazón ASTM

PEDIDO DE PIEZAS DE REPUESTO

Lo sabemos... A veces hay inconvenientes. Pero la diversión no debería detenerse solo porque necesite un perno o un tornillo nuevos. Para pedir piezas de repuesto, consulte nuestro sitio web: www.skywalkertrampolines.com, o llame a nuestra línea directa gratuita de Atención al Cliente al **1-866-603-Jump (5867)**, de lunes a viernes, de 8 a. m. a 5 p. m., hora de la montaña (excepto días festivos).

Nuestro equipo de atención al cliente le hará algunas preguntas para enviarle la pieza de repuesto lo antes posible. Tenga la seguridad de que no es nuestra intención complicarle la vida.

Cuando llame, asegúrese de contar con la siguiente información:
















- El n.º de modelo del producto (consulte la portada de este manual)
- El n.º de referencia y la descripción de la pieza (consulte la lista de piezas anterior)
- La cantidad necesaria (solo usted sabe la respuesta a esta pregunta)

ANTES DE COMENZAR


¡Gracias por elegir Skywalker Trampolines! Estamos tan emocionados como usted por ayudar a que su familia tenga un estilo de vida activo (pero lo más importante: **DIVERTIDO**). Este modelo es uno de nuestros favoritos, y estamos seguros de que a usted también le encantará. Para su comodidad, incluimos una lista de información importante que usted y sus pequeños aventureros al aire libre deben conocer. Asegúrese de reparar todas las advertencias, instrucciones, la información de montaje, mantenimiento y uso de su nuevo producto, porque al final de este manual, encontrará un cuestionario. (Bueno, no es **EN SERIO**, pero si aún está leyendo esto, ¡bien hecho! ¡usted es genial!)

IDENTIFICACIÓN DE PIEZAS

Antes de comenzar, observe los dibujos que aparecen a continuación para asegurarse de que posee todas las piezas. Los números que se encuentran en los recuadros ubicados a la izquierda (números de referencia) lo ayudarán a identificar las piezas durante el montaje.



DIBUJO DE DESPIECE



MONTAJE


LEA LO SIGUIENTE ANTES DE COMENZAR

- Es probable que se necesiten, al menos, **dos adultos y 2 horas** para montar su trampolín (esto dependerá del modelo que tenga y de si usted es o no un superhéroe encubierto).
- Hemos incluido un destornillador Phillips y una llave ajustable para que utilice durante el montaje, pero también puede utilizar sus propias herramientas. Muchas personas consideran que utilizar un taladro eléctrico y un mazo de goma simplifica la tarea.
- Use guantes para proteger sus manos de los puntos de pelizco durante el montaje. Además, ¡es la moda que se está imponiendo!
- Los pasos de montaje hacen referencia a las piezas por medio de sus descripciones y números de referencia (consulte la lista de piezas en la página 3).
- Los pasos de montaje se enumeran en un orden específico, y si no los sigue al pie de la letra, es posible que tenga que empezar de cero nuevamente.
- Lo más importante es que... ¡USTED PUEDE HACERLO! ES EL MEJOR MONTADOR DE TRAMPOLINES QUE EXISTE. Probablemente esto no sea lo más sencillo que ha hecho, pero **validará la pena**. Confíe en nosotros.

PASO 1


¡Registre su trampolín! Para obtener información sobre el registro de garantía, consulte la página 2.

PASO 2



2 Tubo superior con manguito (x8) **3** Tubo de la esquina (x4)

Introduzca dos tubos superiores con manguitos **(2)** en un tubo esquinero **(3)**. Repita este paso para montar las cuatro secciones de esquina.
Asegúrese de que los agujeros de los tubos estén orientados hacia el suelo.



MONTAJE

PASO 3



4 Poste de la pata (x8)


16 Perno M6 x 52 mm (x8)

17 Arandela M6 (x8)

18 Tuerca M6 (x8)

Introduzca dos postes de las patas (4) en los manguitos y asegúrelos usando dos pernos M6 x 52 mm (16), dos arandelas M6 (17) y dos tuercas M6 (18).

Repita este paso hasta que los ocho postes de las patas estén conectados.



PASO 4



5 Pata macho (x1)


6 Pata hembra (x1)

16 Perno M6 x 52 mm (x4)

17 Arandela M6 (x8)

18 Tuerca M6 (x4)

Introduzca una pata macho (5) en una pata hembra (6) y asegúrela con un perno M6 x 52 mm (16), dos arandelas M6 (17) y una tuerca M6 (18). **Repita este paso hasta que haya completado cuatro secciones de pata con forma de U.**



PASO 5




16 Perno M6 x 52 mm (x8)


17 Arandela M6 (x16)

18 Tuerca M6 (x8)

Introduzca una sección de la pata con forma de U en las patas de una sección del armazón de la esquina. Asegúrese de que los agujeros de la pata con forma de U coincidan con los agujeros de las patas de los postes. Asegúrelos con dos pernos M6 x 52 mm (16), cuatro arandelas M6 (17) y dos tuercas M6 (18). **Repita este paso hasta que las cuatro secciones de las patas de la esquina estén conectadas.**




PASO 6



1 Tubo central del armazón (x2)

Pídale ayuda a un amigo y voltee las secciones de las patas de la esquina conectadas para que se apoyen sobre estas. (No se olvide de este paso! No estamos subestimando su fuerza, pero si conecta todo antes de voltearlo, el armazón completo será muy difícil de dar vuelta). Ahora, coloque un tubo central de armazón (1) (curvatura orientada hacia el exterior) entre las dos secciones de patas de la esquina y deslice una contra otra. **Repita este paso en el otro lado.** Ahora, tendrá dos mitades de armazón cuadrado conectadas.



MONTAJE


PASO 7



1 Tubo central del armazón (x2)

Ahora coloque dos tubos centrales de armazón (curvatura orientada hacia el exterior) entre las dos mitades del armazón. Deslice las dos mitades del trampolín una contra otra para crear un armazón que se mantenga firme por sí solo.

Notar: Ajuste todos los pernos para fijarlos en el lugar.



PASO 8





7 Red del cerramiento (x1)



8 Lona de salto (x1)


La red del cerramiento (7) estará preinstalada en la lona de salto (8) (le ahorramos algunos minutos...). Antes de continuar, asegúrese de que cada anillo en V de la lona de salto pase a través del agujero correspondiente de la red del cerramiento.



PASO 9

Coloque la lona de salto en el suelo, dentro del armazón, con la red del cerramiento encima.

Asegúrese de centrar la puerta del cerramiento entre el tercer y el cuarto agujero del tubo central del armazón.




PASO 10



9 Muelle (x1)

Herramienta para el resorte (x1)
21

Se recomienda que use guantes para este paso. Utilizando la herramienta para el resorte (21), enganche el extremo más pequeño de un resorte (9) en el anillo en V que se encuentra a la derecha de la etiqueta de advertencia. Estire el extremo libre del resorte hasta que alcance el cuarto orificio en el tubo central del armazón (1).





MONTAJE

PASO 11



9 Muelle (x1)

Conecte un resorte en el tubo central del armazón del lado opuesto. Ahora debería tener dos resortes conectados.




PASO 12



9 Muelle (x2)

Comience con los resortes recién colocados, cuente 21 anillos en V y 21 agujeros de resorte a la derecha, y conecte un resorte. Después, cuente 21 anillos en V y 21 agujeros de resorte a la izquierda, y conecte un resorte.

Ahora debería tener cuatro resortes conectados, uno en cada lado del trampolín.





PASO 13



9 Muelle (x32)

Hay 16 secciones de conexión en el armazón. Conecte un resorte de cada lado de las 16 conexiones. Ahora debería tener 36 resortes conectados.




PASO 14



9 Muelle (x48)

Ahora conecte todos los resortes restantes en sentido horario. Asegúrese de que los anillos en V y los agujeros del armazón estén alineados correctamente.

(Recuerde que usted es el jefe. Los resortes harán lo que usted diga! Y también lo que digan las personas que están ayudando...)



MONTAJE



PASO 15



10 Almohadilla del resorte (x1)


Estire la almohadilla del resorte **(10)** alrededor del armazón. Ajuste la almohadilla del resorte para que las **ranuras queden justo sobre los manguitos en T**.

Importante: No utilice el trampolín sin la almohadilla del armazón. Esta diseñada para proteger a los pequeños saltarines! Confíe en nuestro consejo.



PASO 16

Mire debajo del trampolín y ubique las correas que se colocaron en la parte interior de la almohadilla del resorte **(10)**. Coloque cada **correa exterior** de modo tal que haya una correa de cada lado del armazón. Coloque las **correas interiores** de modo tal que pase una correa **a través de cada anillo en V**. Ahora ate lazos con todas las correas. (¡Porque si ata nudos, le costará mucho desatarlos nuevamente!) Asegure las esquinas de la almohadilla del resorte con las correas. Enganche las correas a los **anillos en V de cada esquina**.




14

PASO 17



11 Tubo recto (x8)
12 Tubo curvo (x8)
13 Gomaespuma (x16)

Si lo desea, tómese un descanso, porque YA REALIZÓ MÁS DE LA MITAD DEL TRABAJO, y se lo merece. **Si la espuma ya está instalada en los tubos, omita este paso.** De lo contrario, deslice todos los tubos rectos **(11)** y curvos **(12)** dentro de la gomaespuma **(13)**. Si encuentra dificultades a la hora de deslizar los tubos en las gomaespumas, intente echar un poco de agua dentro de las gomaespumas.




PASO 18



19 Tornillo autorroscante (x8)

Introduzca el tubo recto **(11)** en el tubo curvo **(12)** y asegúrelo con un tornillo autorroscante **(19)** **importante: En el tubo curvo hay un extremo que tiene dos agujeros. ¡Asegúrese de que ese extremo esté en la parte superior!**

Repita este paso para fijar juntos los siete tubos rectos y curvos restantes.



15



MONTAJE

PASO 19



14 Tapa del poste (x8)

Importante: La tapa del poste (14) tiene dos lados; uno con un agujero hexagonal y otro con un agujero redondo. Inserte las tapas del poste en los anillos con correa en la parte superior de la red del cerramiento. Asegúrese de que los agujeros hexagonales se encuentren orientados hacia la red y de que los agujeros redondos se encuentren orientados hacia usted.




PASO 20



20 Perno M5 x 44 mm (x8)

Luego coloque un tubo curvo (12) en la tapa del poste (14). Asegúrese de que el lado doblado de los polos del cerramiento esté orientado hacia el centro del trampolín. Asegúrese de que los agujeros del tubo curvo, tapa del poste y anillo con correa estén todos alineados. Luego, coloque un perno M5 x 44 mm (20) para asegurarlos en sus posiciones. **Importante: Asegúrese de colocar el perno en el agujero circular EN PRIMER LUGAR (no el hexagonal); de lo contrario, se puede romper la tapa del poste.** Repita este paso con los tubos curvos restantes.




16

PASO 21

Comience con la puerta del cerramiento, levante uno de los postes montados e inserte el tubo recto (11) en el manguito. Repita este proceso para colocar los siete postes restantes.

Consejo útil: Cuando inserte los postes del cerramiento, tire de la parte central de los postes hacia atrás.




PASO 22



15 Tapa del extremo (x8)

A continuación, introduzca las tapas de los extremos (15) en la parte inferior de los manguitos.




17

MONTAJE

PASO 23


ÚLTIMO PASO: ILLEGÓ A LA RECTA FINAL!

Usando el amarre de plástico incluido, coloque el lettero de seguridad en el armazón del trampolín, cerca de la puerta del cerramiento.



PASO 24

¡Felicidades! Terminó de armar su nuevo trampolín. ¿Vio?... ¡Sabíamos que podía lograrlo! Entonces, aquí viene la verdadera pregunta... ¿está **satisfecho con este producto armado**? Si la respuesta es "sí", **escriba una reseña** en el sitio web del vendedor al que se lo compró. Estaremos muy agradecidos, y si pudiésemos, le daríamos una estrella de oro. ¿Está completamente disconforme y desea que lo separemos? ¡Comuníquese con nosotros directamente! Tenga la seguridad de que no es nuestra intención arruinarle la vida. Haremos todo lo posible para que esté a gusto nuevamente. Consulte la información de contacto en las páginas 2-3.



18

INFORMACIÓN DE CUIDADOS Y MANTENIMIENTO

¡Felicitaciones!, ¡choque los cinco! Ha montado exitosamente su nuevo trampolín cuadrado de 13" con cerramiento de Skywalker Trampolines. La mejor manera de conservar el estado de su trampolín es controlando lo siguiente de forma periódica:

- El relleno del armazón, la red, los tubos del cerramiento o las mangas de gomaespuma no están presentes, están mal colocados o no están asegurados debidamente
- Pinchazos, hilachas, rasgaduras o agujeros en la lona, almohadilla del armazón, red o mangas de gomaespuma
- Deterioro en la costura o tela de la lona, almohadilla del armazón o red
- Resortes rotos o faltantes
- Armazón, pata o tubos del cerramiento doblados o rotos
- Cama o red hundidas
- Protuberancias cortantes en el armazón, sistema de suspensión o tubos del cerramiento

Si observa alguna de las condiciones anteriores, desmonte el trampolín o la red de cerramiento hasta que solicite las piezas de reemplazo!

Traslado del trampolín y el cerramiento

Si se debe mover el trampolín y el cerramiento, deben hacerlo dos personas, mantenerlos horizontales y elevarlos levemente. De ser necesario, puede desarmar el trampolín y el cerramiento para trasladarlos. Para desarmar el trampolín, siga los pasos de montaje en orden invertido. No intente desarmar las secciones del armazón, las patas o las bases antes de haber retirado la lona y los resortes.

¡No olvide visitarnos en la web! **Nos encantaría estar en contacto con usted.**

Sitio web: skywalkertrampolines.com

Facebook: facebook.com/skywalkertrampolines

YouTube: youtube.com/channel/UCUy7EqwIGouk5ovzGpHGw/feed

Pinterest: pinterest.com/swtrampolines

Twitter: twitter.com/swtrampolines?lang=en

Instagram: instagram.com/skywalker_trampolines?hl=en

INSTRUCCIONES DE USO

Para reducir el riesgo de lesiones graves, lea y respete todas las advertencias, precauciones e instrucciones de este manual antes de usar el cerramiento del trampolín. Se incluyen advertencias e instrucciones de cuidado, mantenimiento y uso de este trampolín y cerramiento para promover el uso seguro y agradable de este equipo.

1. Es responsabilidad del propietario y de los supervisores del trampolín y del cerramiento asegurarse de que todos los usuarios sigan las instrucciones de seguridad detalladas en este manual. El trampolín debe utilizarse únicamente bajo supervisión de personas maduras e informadas.
2. Proteja el trampolín y el cerramiento del trampolín del uso no autorizado y sin supervisión. Si utiliza una escalera para subir y bajar del trampolín, asegúrese de quitarla cuando el trampolín y el cerramiento no se utilicen.
3. Asegúrese de que haya espacio suficiente por encima del trampolín y del cerramiento antes de usarlo. Lo ideal es contar con al menos 24 pies (7.3 metros) de espacio libre por encima del suelo. Este espacio debe estar libre de cables, ramas de árboles y otros posibles peligros.
4. La separación lateral es muy importante. No coloque el trampolín ni el cerramiento cerca de paredes, edificios, cercas, aceras y otras áreas de juego. Asegúrese de que el espacio circundante al trampolín y al cerramiento esté siempre despejado.
5. Retire cualquier objeto que pudiera interferir con el uso del equipo. Mantenga el área de los laterales y de la parte inferior del trampolín despejada.
6. Asegúrese de que el trampolín y el cerramiento estén sobre una superficie nivelada antes de usarlos.
7. Siempre realice una inspección del trampolín y del cerramiento antes de cada uso. Asegúrese de que el armazón, la alimohadilla, la red, los tubos del cerramiento y los mangos de gomaespuma estén correctamente colocados. Reemplace cualquier pieza gastada, defectuosa o faltante. (Los usuarios podrían lastimarse si el trampolín y el cerramiento se utilizan cuando se encuentran en mal estado).
8. Salte únicamente cuando la superficie de la lona (como) esté seca. No debe haber viento ni movimiento de aire, o estos deben ser escasos. El trampolín y el cerramiento no deben usarse con vientos racheados o fuertes.
9. Los armazones del trampolín y del cerramiento están hechos de metal. No están conectados a tierra y conducen la electricidad. Por este motivo, existe un riesgo de electrocución. No se permitan luces, calentadores eléctricos, cables de prolongación o electrodomésticos en el trampolín ni en el cerramiento en ningún momento.
10. Use el trampolín y el cerramiento en una zona bien iluminada. Si el trampolín y el cerramiento están en interiores o en zonas con sombra, es probable que tenga que usar iluminación artificial (telecáncil) en la zona.
11. Durante los meses de invierno, deberá quitar los materiales blandos del trampolín y guardarlos en un lugar seco. Si no los quita en los meses de invierno, el frío puede causar daños en los resortes, la lona de salto, la alimohadilla y el cerramiento. La garantía se anulará. Este trampolín y cerramiento están fabricados para usuarios que pesen menos de 250 libras.
12. Los trampolines de más de 20 pulgadas (51 cm) de alto no se recomiendan para niños menores de 6 años de edad.
13. El cerramiento del trampolín debe usarse solo con el tamaño de trampolín para el cual está diseñado.
14. El uso incorrecto y el maltrato del cerramiento del trampolín son peligrosos y pueden causar lesiones graves.
15. No coloque nada en la barrera del cerramiento, o menos que sea un accesorio aprobado por el fabricante o una pieza del sistema de cerramiento.

ADVERTENCIA

¡Mantenga la zona de aterrizaje libre de obstáculos! No permita que los niños jueguen en la zona de aterrizaje. Mantenga la zona de aterrizaje libre de obstáculos. No permita que los niños jueguen en la zona de aterrizaje. Mantenga la zona de aterrizaje libre de obstáculos. No permita que los niños jueguen en la zona de aterrizaje.

¡Mantenga la zona de aterrizaje libre de obstáculos! No permita que los niños jueguen en la zona de aterrizaje. Mantenga la zona de aterrizaje libre de obstáculos. No permita que los niños jueguen en la zona de aterrizaje. Mantenga la zona de aterrizaje libre de obstáculos. No permita que los niños jueguen en la zona de aterrizaje.

¡Mantenga la zona de aterrizaje libre de obstáculos! No permita que los niños jueguen en la zona de aterrizaje. Mantenga la zona de aterrizaje libre de obstáculos. No permita que los niños jueguen en la zona de aterrizaje. Mantenga la zona de aterrizaje libre de obstáculos. No permita que los niños jueguen en la zona de aterrizaje.

ADVERTENCIA

¡Mantenga la zona de aterrizaje libre de obstáculos! No permita que los niños jueguen en la zona de aterrizaje. Mantenga la zona de aterrizaje libre de obstáculos. No permita que los niños jueguen en la zona de aterrizaje. Mantenga la zona de aterrizaje libre de obstáculos. No permita que los niños jueguen en la zona de aterrizaje.

¡Mantenga la zona de aterrizaje libre de obstáculos! No permita que los niños jueguen en la zona de aterrizaje. Mantenga la zona de aterrizaje libre de obstáculos. No permita que los niños jueguen en la zona de aterrizaje. Mantenga la zona de aterrizaje libre de obstáculos. No permita que los niños jueguen en la zona de aterrizaje.


¡Mantenga la zona de aterrizaje libre de obstáculos! No permita que los niños jueguen en la zona de aterrizaje. Mantenga la zona de aterrizaje libre de obstáculos. No permita que los niños jueguen en la zona de aterrizaje. Mantenga la zona de aterrizaje libre de obstáculos. No permita que los niños jueguen en la zona de aterrizaje.

ADVERTENCIA

¡Mantenga la zona de aterrizaje libre de obstáculos! No permita que los niños jueguen en la zona de aterrizaje. Mantenga la zona de aterrizaje libre de obstáculos. No permita que los niños jueguen en la zona de aterrizaje. Mantenga la zona de aterrizaje libre de obstáculos. No permita que los niños jueguen en la zona de aterrizaje.

¡Mantenga la zona de aterrizaje libre de obstáculos! No permita que los niños jueguen en la zona de aterrizaje. Mantenga la zona de aterrizaje libre de obstáculos. No permita que los niños jueguen en la zona de aterrizaje. Mantenga la zona de aterrizaje libre de obstáculos. No permita que los niños jueguen en la zona de aterrizaje.

¡Mantenga la zona de aterrizaje libre de obstáculos! No permita que los niños jueguen en la zona de aterrizaje. Mantenga la zona de aterrizaje libre de obstáculos. No permita que los niños jueguen en la zona de aterrizaje. Mantenga la zona de aterrizaje libre de obstáculos. No permita que los niños jueguen en la zona de aterrizaje.




ADVERTENCIA

¡Mantenga la zona de aterrizaje libre de obstáculos! No permita que los niños jueguen en la zona de aterrizaje. Mantenga la zona de aterrizaje libre de obstáculos. No permita que los niños jueguen en la zona de aterrizaje. Mantenga la zona de aterrizaje libre de obstáculos. No permita que los niños jueguen en la zona de aterrizaje.

¡Mantenga la zona de aterrizaje libre de obstáculos! No permita que los niños jueguen en la zona de aterrizaje. Mantenga la zona de aterrizaje libre de obstáculos. No permita que los niños jueguen en la zona de aterrizaje. Mantenga la zona de aterrizaje libre de obstáculos. No permita que los niños jueguen en la zona de aterrizaje.

¡Mantenga la zona de aterrizaje libre de obstáculos! No permita que los niños jueguen en la zona de aterrizaje. Mantenga la zona de aterrizaje libre de obstáculos. No permita que los niños jueguen en la zona de aterrizaje. Mantenga la zona de aterrizaje libre de obstáculos. No permita que los niños jueguen en la zona de aterrizaje.



POSICIÓN DE LA ETIQUETA DE ADVERTENCIA

El letrero que se muestra anteriormente se cosió a la red del cerramiento del trampolín.

Nota: Las etiquetas y el letrero que se muestran no están representados en su tamaño real.

Las etiquetas que se muestran en esta página se han colocado en el trampolín en los lugares indicados. El propietario deberá colocar el letrero con las instrucciones de seguridad. Si alguna de las etiquetas o el letrero faltan o son ilegibles, llame a nuestra línea directa gratuita de Atención al Cliente al 1-866-603-JUMP (5867), de lunes a viernes, de 8 a. m. a 5 p. m., hora de la montaña, para pedir una etiqueta o un letrero de reemplazo.


INSTRUCCIONES Y LECCIONES MODELO

Las siguientes lecciones son ejemplos de un programa instructivo. Deberían seguir un debate y una demostración completos de la mecánica del cuerpo entre ta/s persona/s que supervisa/n y el/los estudiante/s.

1. Montaje y desmontaje: Demostración y práctica de técnicas correctas.
2. Principios básicos del rebote: Demostración y práctica.
3. Frenado: Demostración y práctica. Frenar tras recibir la indicación.
4. Caída de manos y de rodillas: Demostración y práctica, refuerzo del aterrizaje y la alineación de cuatro puntos.


Lección 1: Principios básicos del rebote

1. Comience parado con la cabeza erguida y los ojos en dirección a la almohadilla del armazón.
2. Balancee los brazos hacia adelante y hacia arriba en un movimiento circular.
3. Junte los pies y apunte hacia abajo con los dedos de los pies mientras está en el aire.
4. Mantenga los pies separados, aproximadamente 15 pulgadas, cuando vaya a aterrizar en la lona.




Lección 2: Caída de rodillas

1. Comience a rebotar mientras está parado, mantenga la mirada en la almohadilla del armazón.
2. Aterrice sobre sus rodillas, y mantenga la espalda y el cuerpo erguidos.
3. Párese nuevamente.




Lección 3: Caída de manos y de rodillas

1. Comience a rebotar mientras está parado, mantenga la mirada en la almohadilla del armazón.
2. Aterrice sobre la lona con las manos y rodillas.
3. Empújese con las manos y párese.




Lección 4: Caída de espaldas

1. Comience con un rebote bajo y aterrice de espalda.
2. Inclíne el mentón hacia su pecho mientras aterrice.
3. Párese hacia adelante y empújese con las piernas para volverse a parar.




Lección 5: Caída sentada

1. Aterrice sentado con las piernas paralelas a la lona.
2. Coloque las manos sobre la lona al lado de su cadera.
3. Empújese con las manos para volver a pararse.



Lección 6: Caída de frente

1. Comience con un rebote bajo y aterrice en la lona boca abajo.
2. Mantenga la cabeza erguida y los brazos extendidos hacia la lona.
3. Empújese con los brazos para volver a pararse.




Lección 7: Media vuelta

1. Comience con la posición de caída de frente y empújese hacia la izquierda o la derecha con los brazos para empezar a girar su cuerpo en la dirección opuesta.
2. Gire la cabeza y los hombros en la misma dirección que su cuerpo.
3. Mantenga la espalda paralela a la lona y la cabeza erguida.
4. Después de completar la media vuelta, aterrice de frente.



Lección 8: Caderas giratorias

1. Comience con una caída en posición sentada.
2. Gire la cabeza hacia la izquierda o la derecha y balancee los brazos hacia arriba en la misma dirección.
3. Gire las caderas en la misma dirección que la cabeza y los brazos, de manera que complete un giro.
4. Aterrice en posición sentada.
5. Mantenga la espalda paralela a la lona y la cabeza erguida.
6. Después de completar la media vuelta, aterrice de frente.



Una vez que aprende cada uno de las lecciones, se debe estimular al aprendiz a que diseñe y organice rutinas, haciendo énfasis en la buena forma. El instructor puede juzgar o calificar a los estudiantes y organizar grupos para profundizar la instrucción de acuerdo a la capacitación de cada estudiante.

Para estimular el interés en la competencia, puede presentar el juego "Trampolín Horse". Antes de que comience el juego, los estudiantes deben enumerarse. Para comenzar el juego, el estudiante número 1 debe realizar una acrobacia. Luego el estudiante número 2 se sube al trampolín, realiza la misma acrobacia y agrega una segunda acrobacia. El estudiante número 3 se sube al trampolín, realiza las acrobacias 1 y 2, y agrega una tercera acrobacia. De este modo, la serie de acrobacias se extiende continuamente. La primera persona que se divide de realizar una de las acrobacias de la serie recibe la letra "H" y comienza una nueva serie con una acrobacia. Si alguien pierde de nuevo, se le otorgará la letra "O". Si alguien completa la palabra "H-O-R-S-E" (caballo), será eliminado del juego. El último concursante que permanezca en el juego será el ganador. La planificación de las lecciones a partir de este punto debe facilitarse a través del contacto con un instructor de trampolín certificado.

INFORMACIÓN DE SEGURIDAD DEL TRAMPOLÍN

Con el uso del trampolín, como en todos los deportes recreativos activos, los participantes pueden lesionarse. Sin embargo, pueden tomarse medidas para reducir el riesgo de lesión. En esta sección, se identifican los principales patrones de accidentes y se detallan las responsabilidades de los supervisores y de los usuarios relativos a la prevención de accidentes.

CLASIFICACIÓN DE ACCIDENTES

Volteretas (saltos mortales): Aterrizar con la cabeza o el cuello, incluso en medio de la lona del trampolín, aumenta el riesgo de que se quiebre la espada o el cuello, lo cual puede causar parálisis o la muerte. Este tipo de eventos puede ocurrir cuando un usuario comete un error al tratar de realizar una voltereta (salto mortal) hacia adelante o hacia atrás. No realice volteretas (saltos mortales) en este trampolín para patio.

Varios usuarios: Si hay más de una persona a la vez en el trampolín, aumenta la posibilidad de que un usuario se lesione al perder el control de su salto. Los usuarios pueden chocar entre sí, caerse del trampolín, caer sobre o a través de los resortes, o aterrizar incorrectamente en la lona. El usuario de menor peso es el más propenso a resultar herido.

Subirse y bajarse del trampolín: La lona del trampolín está a varios pies sobre el nivel del suelo. Saltar del trampolín al suelo o a cualquier otra superficie puede resultar en lesiones. Saltar al trampolín desde una azotea, plataforma u otro objeto también presenta un riesgo de lesión. Los niños más pequeños quizá necesiten ayuda para subirse o bajarse del trampolín. Suba y baje siempre cuidadosamente del trampolín. No pise los resortes ni la almohadilla del armazón. No se agarre de la almohadilla del armazón para trepar al trampolín.

Golpear el armazón o los resortes: Puede lesionarse como resultado de golpear el armazón o caer a través de los resortes mientras salta, o se sube o baja del trampolín. Permanezca en el centro de la lona cuando salte. Asegúrese de mantener la almohadilla del armazón en su lugar para cubrir el armazón. La almohadilla del armazón no está fabricada para soportar el peso del usuario del trampolín. No se pare ni salte directamente sobre la almohadilla del armazón.

Pérdida del control: Los usuarios que pierden control de sus saltos pueden aterrizar incorrectamente en la lona, en el armazón o en los resortes, o caer fuera del trampolín. Un salto controlado es cuando se aterriza en el mismo lugar del que se saltó. Antes de aprender un truco más difícil, debe poder realizar un truco una y otra vez de forma controlada. Intentar realizar un truco sin contar con los niveles de habilidades requeridos aumenta la probabilidad de perder el control. Para recuperar el control y detener el salto, flexione las rodillas de forma pronunciada al aterrizar.

Consumo de alcohol o drogas: La posibilidad de lesión aumenta cuando un usuario ha consumido alcohol o drogas. Estas sustancias afectan el tiempo de reacción, el juicio y la coordinación física de una persona.

Toparse con objetos: saltar en un trampolín mientras otras personas, mascotas u objetos están debajo de este aumentará la posibilidad de que alguien resulte herido. Saltar en el trampolín mientras sostiene un objeto, especialmente uno que sea cortante o frágil, aumentará la probabilidad de lesiones. Colocar un trampolín demasiado cerca de cables eléctricos, ramas de árboles u otros objetos puede aumentar la probabilidad de lesiones.

Mal mantenimiento del trampolín: Los usuarios pueden resultar heridos si se utiliza un trampolín en mal estado. Las lonas rasgadas, los armazones dobladas, los resortes rotos o las almohadillas del armazón perdidas, por ejemplo, se deben reemplazar antes de permitir que una persona salte. Inspeccione el trampolín antes de cada uso.

Condiciones climáticas: un trampolín mojado es demasiado resbaloso para saltar de forma segura. Los vientos racheados o fuertes pueden hacer que los usuarios pierdan el control. Para reducir la posibilidad de lesión, use el trampolín solo cuando el clima sea adecuado.

Acceso: para evitar el acceso al trampolín de los niños más pequeños sin supervisión, debe quitar siempre la escalera opcional de acceso y guardarla en un lugar seguro cuando no utilice el trampolín.

INFORMACIÓN DE SEGURIDAD DEL CERRAMIENTO

NECESIDADES DE SEGURIDAD PARA EL CERRAMIENTO DEL TRAMPOLÍN

El cerramiento de un trampolín es un producto de recreación. La información de esta página identifica las precauciones de seguridad importantes. Las precauciones no incluyen todas las posibilidades, dado que un cerramiento puede utilizarse de maneras que este manual podría no cubrir en su totalidad.

Para evitar los pellizcos y los cortes durante el uso del cerramiento, el trampolín debe contar con una almohadilla en el armazón (consulte las instrucciones del fabricante del trampolín). La almohadilla del armazón debe colocarse sobre el trampolín antes de montar el cerramiento. La almohadilla del armazón reduce las posibilidades de lesiones por contactos accidentales con los resortes o el armazón.

USO SEGURO DEL CERRAMIENTO

Supervisión de los niños por parte de adultos

Los niños que utilicen el trampolín con un cerramiento deben ser supervisados por un adulto. Los niños pequeños deben ser supervisados constantemente. Los adultos deben prestar especial atención a lo siguiente:

- Las cosas que los niños llevan al cerramiento.
- Las actividades de los niños dentro del cerramiento.
- Las condiciones dentro del cerramiento mientras los niños lo están usando.
- La forma en que los niños entran y salen del cerramiento.

A continuación, se detalla más información sobre el uso seguro del cerramiento:

Riesgo de electrocución asociado con el armazón de metal del trampolín y del cerramiento

Los armazones del trampolín y del cerramiento están hechos de acero galvanizado. No están conectados a tierra y conducirán la electricidad. Por este motivo, existe un riesgo de electrocución. No se permiten luces, calentadores eléctricos, cables de prolongación o electrodomésticos en el trampolín ni en el cerramiento en ningún momento.

Peligros asociados con la entrada y salida del cerramiento del trampolín

El cerramiento instalado en un trampolín está elevado del suelo. La altura del cerramiento aumenta el riesgo de una caída cuando un usuario entra o sale del cerramiento. Es posible que a los niños pequeños, sobre todo, les cueste entrar y salir del cerramiento. Para reducir el riesgo de caídas, ayude siempre a los niños pequeños a entrar y salir del cerramiento.

Entre y salga del cerramiento del trampolín solamente por medio de la puerta del cerramiento (la abertura en las paredes de la red). La lona del trampolín (cama) y las paredes de la red del cerramiento son piezas separadas. Ningún usuario, especialmente los niños pequeños, debe salir del cerramiento y quedarse entre la lona y las paredes de la red. Intentar salir de esta forma genera un riesgo de asfixia por quedar atrapado entre el armazón del trampolín y las paredes de la red.

La oscuridad aumenta el riesgo de una caída cuando un usuario entra o sale del cerramiento. No utilice el trampolín a menos que haya una iluminación adecuada.

Peligros asociados con animales u objetos cortantes o frágiles

Para evitar que el cerramiento y el trampolín se dañen, no deje entrar mascotas u otros animales dentro del cerramiento. Los garras y los dientes de los animales pueden dañar la red. No salte en el trampolín mientras sostiene o usa un objeto cortante o frágil.

MÉTODOS DE PREVENCIÓN DE ACCIDENTES

LA FUNCIÓN DEL SUPERVISOR EN LA PREVENCIÓN DE ACCIDENTES

Los supervisores de los usuarios del trampolín tienen la responsabilidad de proporcionar supervisión informada y madura. Deben conocer y hacer cumplir todas las reglas y advertencias impresas en este manual para minimizar la probabilidad de accidentes y lesiones. También deben informarles estas reglas a los usuarios. Durante períodos de tiempo en los que la supervisión no esté disponible o no sea la adecuada, el trampolín debe desarmarse, colocarse en un área segura o protegerse del uso no autorizado. Otra opción que se debe considerar es abrir el trampolín con una lona pesada que pueda asegurarse con candados y cadenas. El supervisor tiene la responsabilidad de asegurarse de que el lettero con las instrucciones de seguridad del trampolín permanezca en el trampolín y de que los usuarios estén informados acerca de estas instrucciones.

LA FUNCIÓN DEL USUARIO EN LA PREVENCIÓN DE ACCIDENTES

Es obligatorio educar al usuario para su seguridad. Los usuarios deben primero aprender un rebote bajo y controlado, y luego aprender las posiciones y combinaciones básicas de aterrizaje antes de pasar a las habilidades intermedias. Los usuarios deben entender por qué deben lograr "controlar" sus movimientos antes de poder comenzar a pensar en otros movimientos. Entender la progresión adecuada de las habilidades de saltar en un trampolín debe ser la primera lección. Revise este manual para conocer las técnicas básicas de uso del trampolín. Siga las reglas del lettero con las instrucciones de seguridad del trampolín (consulte el paso [22] de las instrucciones de montaje). Para obtener información adicional u otros materiales instructivos, comuníquese con un instructor de trampolín certificado.

INSTRUCCIONES DE SEGURIDAD DEL TRAMPOLÍN

Para el supervisor

Antes de usar el trampolín, lea las instrucciones. Aplique todas las reglas de seguridad. Familiarícese con la información de este manual para poder ayudar a los nuevos usuarios a aprender los saltos básicos y a todos los usuarios a respetar la seguridad del trampolín. Todos los usuarios del trampolín deben tener una supervisión madura e informada, independientemente de su habilidad o edad. Este trampolín no se recomienda para niños menores de 6 años de edad. Inspeccione el trampolín antes de usarlo. No utilice el trampolín sin la almohadilla del armazón firmemente colocada para cubrir el armazón. No utilice el trampolín mojado o cuando esté ventoso. Las lonas, los resortes o las piezas del armazón desgastados o dañados deben reemplazarse de inmediato.

Saltar

Aprenda cuidadosamente los saltos y las posiciones corporales básicas antes de intentar habilidades más avanzadas. Conozca sus propios límites a la hora de realizar cada uno de los saltos en el trampolín. Estudie este manual para aprender a realizar los saltos básicos. Para dejar de rebotar, flexione las rodillas en cuanto sus pies entren en contacto con la lona del trampolín. Aprenda esta habilidad antes de intentar otras.

PELIGROS ASOCIADOS CON LOS VIENTOS FUERTES

Los vientos fuertes pueden desplazar o volar un trampolín con un cerramiento. Si esto sucede, cualquiera que se encuentre en su camino, o en el interior del cerramiento, puede resultar lesionado. Si se esperan vientos fuertes, desarme la red del cerramiento y sujete el armazón del trampolín al suelo o lleve el trampolín y el cerramiento a un lugar protegido. El único método seguro para proteger su trampolín y el entorno circundante durante los vientos fuertes es desmontar la unidad por completo y guardarla bajo techo. La garantía no cubre los daños ocasionados por el viento o por el clima.

GARANTÍA LIMITADA

Skywalker Holdings, LLC garantiza que sus productos no tendrán materiales ni mano de obra defectuosos en condiciones de uso y servicio normales. **El armazón de acero tiene una garantía de tres (3) años a partir de la fecha de compra. Los demás piezas tienen una garantía de un (1) año a partir de la fecha de compra.** La cobertura de la garantía se extiende solo al comprador minorista original a partir de la fecha de compra. Esta garantía solo será válida en relación con productos de uso residencial. Los productos de uso comercial, por ejemplo, aquellos utilizados en escuelas y guarderías, no serán cubiertos.

¿QUÉ CASOS NO ESTARÁN CUBIERTOS?

Daño climático: La garantía no cubre daños por efectos o actos de la naturaleza, como terremotos, vientos, huracanes, tornados, relámpagos, lluvias, incendios, nieve, calor o frío excesivo o daño causado por el sol. Durante los meses de invierno, deberá quitar los materiales blandos del trampolín y guardarlos en un lugar seco, lejos de la nieve. Si el trampolín está desprotegido durante los meses de invierno, algunos componentes tales como los resortes, la lona de salto, la almohadilla y el cerramiento, se pueden ver afectados, lo cual anulará la garantía.



Decoloración y óxido: Nuestros productos están totalmente galvanizados. Skywalker no ofrece garantía contra el óxido o la corrosión. Es posible que algunas regiones tengan mayor contenido salino, mayor humedad, o lluvias y nieve más fuertes. Skywalker no ofrece garantía por la decoloración. Les aconsejamos a los clientes que utilicen un protector de rayos UV en la almohadilla del armazón para extender la duración del producto.



Pérdida o daños del producto debido a lo siguiente: Los pérdidas o los daños causados durante el envío, o por el abuso, el uso incorrecto, inadecuado o anormal, o la reparación no autorizada, no estarán cubiertos por esta garantía, e incluso, podrían anularla.



Piezas de repuesto no autorizadas: La garantía quedará anulada si se producen defectos o daños relacionados con el uso de piezas de repuesto no autorizadas. Todas las piezas de repuesto deben ser provistas por un agente autorizado.



Servicio de montaje: La garantía no cubre actos u omisiones por parte de un servicio de montaje externo. Es responsabilidad del cliente revisar todos las cajas y comprobar que todos los componentes estén incluidos y en el estado adecuado, antes de realizar la instalación.



INSPECCIÓN Y PIEZAS DE REPUESTO:

1. Su trampolín DEBE SER INSPECCIONADO AL ABRIR EL EMBALAJE Y MONTARLO, Y POSTERIORMENTE DE FORMA PERIÓDICA. LAS PARTES DAÑADAS, ROTAS O DESGASTADAS DEBERÁN SER REEMPLAZADAS DE INMEDIATO, ANTES DE SER USADAS.
2. Llame al Departamento de Atención al Cliente de Skywalker Trampoline al 1-866-603-5867, para realizar una reclamación de garantía. Este preparado para proporcionar la siguiente información: nombre, dirección de envío, una copia de su factura de compra original, una descripción breve del problema y su causa, y los números de modelo y de serie del trampolín. También es posible que le pidamos fotografías de las piezas dañadas/defectuadas.
3. Luego de revisar su información y de examinar las fotografías, Skywalker Trampolines decidirá si la garantía cubrirá la pieza o no. Si la cubre, se le enviará una pieza de repuesto.

NOTA: Toda la información solicitada deberá ser provista para que podamos revisar su reclamación de garantía.

Para solicitar piezas de repuesto para su producto, visite www.skywalkertrampolines.com

Skywalker Holdings, LLC, PO Box 574, Brigham City, UT 84302 EE. UU.
Impreso en China © 2020 Skywalker Holdings, LLC

NOTA: SKYWALKER HOLDINGS, LLC NO ES RESPONSABLE DE LOS DAÑOS INDIRECTOS, ESPECIALES O CONSECUENTES QUE SURJAN EN RELACIÓN CON EL USO O DESEMPEÑO DEL PRODUCTO O DE OTROS DAÑOS RELATIVOS A CUALQUIER PÉRDIDA ECONÓMICA, PÉRDIDA DE PROPIEDAD, PÉRDIDA DE INGRESOS O GANANCIAS, PÉRDIDA DEL DISFRUTE O DEL USO, COSTO DE EXTRACCIÓN, INSTALACIÓN U OTROS DAÑOS CONSECUENTES. ALGUNOS ESTADOS NO PERMITEN LA EXCLUSIÓN O LIMITACIÓN DE LOS DAÑOS INCIDENTALES O CONSECUENTES. POR CONSIGUIENTE, ES POSIBLE QUE LA LIMITACIÓN ANTERIOR NO SE APLIQUE A SU CASO.

LA GARANTÍA EXTENDIDA POR EL PRESENTE REEMPLAZA A TODA OTRA GARANTÍA, Y CUALQUIER GARANTÍA IMPLÍCITA DE COMERCIABILIDAD O IDONEIDAD PARA UN PROPÓSITO EN PARTICULAR ESTÁ LIMITADA EN SU ALCANCE Y DURACIÓN A LOS TÉRMINOS ESTABLECIDOS EN EL PRESENTE. ALGUNOS ESTADOS O PAÍSES NO PERMITEN QUE HAYA LIMITACIONES RESPECTO A LA DURACIÓN DE UNA GARANTÍA IMPLÍCITA. POR CONSIGUIENTE, ES POSIBLE QUE LA LIMITACIÓN ANTERIOR NO SE APLIQUE A SU CASO. ESTA GARANTÍA LE CONCEDE DERECHOS LEGALES ESPECÍFICOS. PUEDE TENER OTROS DERECHOS QUE VARÍAN DE ESTADO A ESTADO O DE PAÍS A PAÍS.

ESTA GARANTÍA SERÁ VÁLIDA ÚNICAMENTE EN EL PAÍS EN EL QUE SE ADQUIRIÓ EL PRODUCTO.